


THE RADIUS OF THE TREE PROTECTION ZONE (TPZ) IS CALCULATED BY MULTIPLYING THE TRUNK DIAMETER AT BREAST HEIGHT (DBH) BY TWELVE (12).

Ex. A tree with a trunk diameter of 12" would need a TPZ with a radius of at least 144" (12') or 24' across.

ORANGE SNOW FENCING AROUND

2"Ø GALVANIZED IRON POSTS, TYP.



PLAN VIEW



2x4 BOARD

SIDEWALK

6'-0"

2'-0"

SIGN

10'-0" MAX.  
POST TO POST

10'-0" MAX.  
POST TO POST

2"Ø GALVANIZED IRON POSTS, TYP.

ORANGE SNOW FENCING AROUND

**SIGNIFICANT TREE PROTECTIVE FENCE**

SCALE: 1/4" = 1'-0"